
TEMPLATE AND MAIN INSTRUCTIONS FOR MODEL NO. 85V EN7 AND ITS EQUIVALENTS






E. & O. E. ©Kenwa, Osaka-Japan. 04-10A-TI85V-EN7

For further details on instructions and adjustments please refer to the installation instruction sheet No. 68-1.

Spring Power Adjustment: Size NO.OF TURNS DIRECTION * : Factory pre-set at size EN7

TEMPLATE AND MAIN INSTRUCTIONS FOR MODEL NO. 85V EN7 AND ITS EQUIVALENTS





E. & O. E. ©Kenwa, Osaka-Japan. 04-10A-TI85V-EN7

For further details on instructions and adjustments please refer to the installation instruction sheet No. 68-1.

* : Factory pre-set at size EN7